

HITACHI

Inspire the Next

Digital TV Recorder

Model
HDR162



Instruction manual

To obtain the best performance and ensure years of trouble-free use, please read this instruction manual completely.



INDEX

IMPORTANT SAFEGUARDS	2
SOME DOS AND DON'TS ON THE SAFE USE OF EQUIPMENT	6
POWER CORD (MAINS LEAD)	7
SAFETY PRECAUTIONS	7
FUNCTIONS	8
CONTENTS OF PACKAGING	8
REMOTE CONTROL	10
GETTING STARTED	10
FRONT AND BACK PANEL	11
CONNECTION DIAGRAMS	12
REMOTE CONTROL & FUNCTIONS	13
MENU INTERFACE	15
FIRST TIME INSTALLATION	15
MAIN MENU	15
1. CHANNEL LIST	15
1.1. NAVIGATING CHANNEL LIST	16
1.2. DELETING CHANNEL	16
1.3. EDIT CHANNELS	16
1.4. ADDING LOCKS TO CHANNELS	16
1.5. SETTING FAVOURITE LIST	16
2. PROGRAMME GUIDE (7 DAYS EPG)	17
2.1. PROGRAMME OPTIONS	17
2.1.1. SELECT CHANNEL	18
2.1.2. RECORD / DELETE TIMER	18
2.1.3. RECORD SERIES / DELETE SERIES TIMER	18
2.1.4. CHECK CONFLICTS	18
2.1.5. SET REMINDER / DELETE REMINDER	18
2.1.6. SPLIT RECORD	19
2.1.7. MULTIPLE / ALTERNATIVE TIMER RECORD	19
3. TIMERS	20
4. RECORDINGS LIBRARY	21
4.1. PLAY OPTIONS	22
4.1.1. PLAY FROM START	22
4.1.2. RESUME	22
4.1.3. PLAY FROM OFFSET	22
4.1.4. MANAGE CHAPTERS	22
4.1.5. CREATE ARCHIVE (ARCHIVE MANAGEMENT)	22
EDIT RECORDINGS	23
MAIN TITLE	23
RECORDING TITLE	23
4.2. CHAPTER OPTIONS	24
4.2.1. CREATE NEW CHAPTER MARK	24
4.2.2. FORWARDS TO NEXT CHAPTER	24
4.2.3. BACK TO START OF CHAPTER	24
4.2.4. BACK TO PREVIOUS CHAPTER	24
5. SETUP	25
5.1. RECORDINGS	25
5.1.1. MAX TIMESHIFT	25
5.1.2. AUTO DISCARD	25
5.1.3. FORMAT DISK	26
5.1.4. HARD DISK INFO	26
Recording Format	27
Unrecordable Material	27
Hard Disk Operation (Recording / Playback / Time Shift Recording)	27
5.2. CONFIGURATION	28
5.2.1. TV TYPE	28
5.2.2. TV OUT	28
5.2.3. VCR OUT	28
5.2.4. FAVOURITE MODE	28
5.2.5. CHANNEL LIST	28
5.2.6. SCAN ENCRYPTED CHANNELS	28
5.2.7. RECEIVER UPGRADE - OAD	29
5.2.8. PARENTAL LOCKING	29
5.2.8.i. MENU LOCK	29
5.2.8.ii. SET PIN	29
5.3. LANGUAGE	30
5.4. INSTALLATION	30
5.4.1. AUTOMATIC CHANNEL SCAN	30
5.4.2. MANUAL CHANNEL SCAN	30
5.4.3. FIRST TIME INSTALLATION	31
6. MESSAGES	31
7. SPECIFIC FUNCTIONS OF REMOTE CONTROL	31
TIME SHIFTING (PAUSE LIVE RECORDING)	33
8. TROUBLE SHOOTING GUIDE	34
9. TECHNICAL SPECIFICATIONS	35
10. UK GUARANTEE	37
11. IMPORTANT NOTICE:	38
DIGITAL SWITCHOVER AND YOUR TV EQUIPMENT	38

IMPORTANT SAFEGUARDS

CAUTION: Please read all of these instructions before you operate this product and save these instructions for later use.

Electrical energy can perform many useful functions. This product has been engineered and manufactured to assure your personal safety. BUT IMPROPER USE CAN RESULT IN POTENTIAL ELECTRICAL SHOCK OR FIRE HAZARDS. In order not to defeat the safeguards incorporated in this product, observe the following basic rules for its installation, use and servicing.

1. Power Supply

The receiver should be plugged into a 220 - 240V AC 50Hz supply only.

2. Leads

Ensure the power supply lead, and all other leads are positioned so they are not likely to be walked on or pinched by objects placed on or against them. Pay particular attention to the power lead, where it enters the mains plug and where it comes out of the receiver. Do not connect or adjust leads when the receiver is plugged in.

3. Battery Disposal

Please ensure that exhausted batteries from the remote control handset are disposed of safely in accordance with local government rules.

4. Read Instructions

All the safety and operating instructions should be read before the product is operated.

5. Retain Instructions

The safety and operating instructions should be retained for future reference.

6. Heed Warnings

All warnings on the product and in the operating instructions should be adhered to.

7. Follow Instructions

All operating and use instructions should be followed.

8. Cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

9. Attachments

Do not use attachments not recommended by the product manufacturer as they may cause hazards.

10. Water, Moisture and Temperature

Do not use this product near water, for example: near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming and the like.

Do not leave or use the receiver in a hot, cold or humid area. Do not allow the receiver to get wet - from drips or splashes - as this may be dangerous. Do not place water filled objects such as flower vases on the top of the receiver.

11. Accessories

Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

12. Transportation

A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.

13. Ventilation

Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

14. Power Sources

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

15. Grounding or Polarization

This product is provided with one of the following types of plugs. If the plug should fail to fit into the power outlet, please contact your electrician. Do not defeat the safety purpose of the plug.

- a. Two-wire type (mains) plug.
- b. Three-wire grounding type (mains) plug with a grounding terminal. This plug will only fit into a grounding type power outlet.

16. Power-Cord Protection

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

17. Lightning

For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the cable system. This will prevent damage to the product due to lightning and power-line surges.

18. Overloading

Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

19. Object and Liquid Entry

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

20. Servicing

Ensure the person who services your receiver is qualified to do so. Do not remove the cover yourself as you could get an electric shock. We are proud to offer a high-quality product. To keep this level of quality, your receiver should be serviced at an authorised service centre.

21. Damage Requiring Service

Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- a. When the power-supply cord or plug is damaged.
 - b. If liquid has been spilled, or objects have fallen into the product.
 - c. If the product has been exposed to rain or water.
 - d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
 - e. If the product has been dropped or damaged in any way.
 - f. When the product exhibits a distinct change in performance, this indicates a need for service.
- Microsoft® and Windows® are registered trademarks of Microsoft Corporation in the United States and/or other countries.

- PC/AT is a registered trademark of International Business Machines Corporation in the United States.
- Macintosh® is a registered trademark of Apple Computer, Inc. in the United States and/or other countries.
- All other company or product names are trademarks or registered trademarks of their respective companies.
- Some IC chips in this product include confidential and/or trade secret property belonging to Texas Instruments. Therefore you may not copy, modify, adapt, translate, distribute, reverse engineer, reverse assemble or discompile the contents thereof.

22. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

23. Safety Check


Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.





24. Wall or Ceiling Mounting

This product should be mounted to a wall or ceiling only as recommended by the manufacturer.

25. Heat and Flames

The receiver should not be placed near to naked flames or sources of intense heat, such as an electric fire. Ensure that no naked flames sources, such as lighted candles are placed on top of the receiver.



	WARNING RISK OF ELECTRIC SHOCK	
	<i>The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock of persons.</i>	
	<i>The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.</i>	



This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed at the end of life separately from your household waste. There are separate collection systems for recycling in the EU.

For more information, please contact the local authority or your retailer where you purchased the product.

SOME DOS AND DON'TS ON THE SAFE USE OF EQUIPMENT

This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured.

DO read the operating instructions before you attempt to use the equipment.

DO ensure that all electrical connections (including the mains plug, extension leads and inter-connections between the pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug before making or changing connections.

DO consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment.

DO be careful with glass panels or doors on equipment.

DO route the mains lead so that it is not likely to be walked on, crushed, chafed, or subjected to excessive wear and tear or heat.

DON'T remove any fixed cover as this may expose dangerous voltages.

DON'T obstruct the ventilation openings of the equipment with items such as newspapers, tablecloths, curtains, etc. Overheating will cause damage and shorten the life of the equipment.

DON'T allow electrical equipment to be exposed to dripping or splashing, or objects filled with liquids, such as vases, to be placed on the equipment.

DON'T place hot objects or naked flame sources such as lighted candles or nightlights on, or close to equipment. High temperatures can melt plastic and lead to fires.

DON'T use makeshift stands and **NEVER** fix legs with wood screws - to ensure complete safety always fit the manufacturer's approved stand or legs with the fixings provided according to the instructions.

DON'T use equipment such as personal stereos or radios so that you are distracted from the requirements of traffic safety. It is illegal to watch television whilst driving.

DON'T listen to headphones at high volume, as such use can permanently damage your hearing.

DON'T leave equipment switched on when it is unattended unless it is specifically stated that it is designed for unattended operation or has a stand-by mode. Switch off using the switch on the equipment and make sure that your family know how to do this. Special arrangements may need to be made for infirm or handicapped people.

DON'T continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way - switch off, withdraw the mains plug and consult your dealer.

ABOVE ALL

--- NEVER let anyone especially children push anything into holes, slots or any other opening in the case - this could result in a fatal electrical shock;

--- NEVER guess or take chances with electrical equipment of any kind

--- it is better to be safe than sorry!

POWER CORD (MAINS LEAD)



Do not place the product where a piece of furniture or other heavy object could trap the power cord (mains lead). Handle the power cord by the plug. Do not pull out the plug by tugging the cord and never touch the power cord when your hands are wet as this could cause a short circuit or electric shock. Never make a knot in the cord or tie it with other cords. The power cords should be routed in such a way that they are not likely to be stepped on. A damaged power cord can cause fire or give you an electrical shock. Check the power cord periodically to see if it is damaged. If it is damaged, please ask an approved service agent to replace it.

For your own safety read following instructions carefully before attempting to connect this device to the mains.

This unit is designed to operate on a 220V-240V AC - 50Hz supply only. Connecting it to other power sources may damage it. Ensure that the supply corresponds to the information on the rating label on the bottom of the unit.

This digital terrestrial receiver is supplied with a moulded mains plug. This plug must not be cut off as it may contain a special radio interference filter, the removal of which could lead to impaired performance. If you wish to extend the lead, obtain an appropriate safety approved extension lead or consult your dealer.

Observe the manufacturers instructions when connecting extension leads to the set. Check the fuse rating on the new plug, this should be fitted with a 5 Amp fuse which conforms to either ASTA or BSI. The mains plug is the disconnect device and therefore must remain readily operable.

(BS1362) approvals, these are easily identifiable by either the  or  symbols. If you are in any doubt about the installation of an extension lead, please consult a competent electrician.



This symbol means that this unit is double insulated. An earth connection is not required.

CAUTION

To prevent electric shock, do not remove the cover. No user serviceable parts inside. Refer servicing to qualified service personnel. Disconnect from the mains supply before cleaning.

SAFETY PRECAUTIONS

Power Source.

This unit should only be connected to a 220-240V AC 50-60 Hz power supply. Do not connect to any other supply.

Power Lead.

Do not place the lead where it may be stepped on or tripped over. Do not place heavy objects on the lead. If the lead becomes cut or damaged, please disconnect the unit from the mains supply.

The mains plug or the appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.

Location.

Place on a solid base such as a shelf or in a TV cabinet or similar. Do not place near heat sources such as radiators, fires or similar.

Do not block ventilation holes or place in a location that does not allow a free airflow.

Do not place the unit near water or in high humidity areas. Avoid splashing. If the unit does get wet please call an approved service agent.

Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

- To prevent electric shock, do not remove any cover.
- If anything goes wrong, don't try and fix it yourself, get a qualified service agent to look at it.
- Do not expose this equipment to dripping or splashing or place any objects filled with liquids, such as vases, on the equipment.
- Never put a naked flame source on or near the equipment.
- Small parts. Do not let young children play with the equipment.
- Do not move your device for 20 seconds after removing the power to ensure that the actuator is completely locked. This helps prevent the media and the heads from accidental damage due to vibration, moving or shipping.
- Do not switch the power ON or OFF, during HDD initialization.








FUNCTIONS

1. Menu Language: English
2. Channel lock, Menu lock
3. Channel list sorted by D-book logical channel numbers.
4. Channel list name editing option.
5. BBC UK Compliant Over Air Download.
6. PIP (Picture in picture)
7. Time shift – pause live TV.
8. One button record (Instant recording of channels).
9. Dual recordings at the same time.
10. Split and series recordings support.
11. Ability to record one channel while watching another channel.
12. X1/4, X1/2, X1, X2, X4, X8, X16, X32 forward and backward play options.
13. Play list shows available recordings (Event name, Start time, Duration, delete/playback permission)
14. Timers list shows scheduled recordings (Event name, Start time, Duration, change/delete/playback permission)
15. Record timer via 7 day EPG
16. Records DVB subtitles (If any are broadcasted by the broadcaster).
17. Automatic/Manual channel search.
18. Guided first time installation.
19. 200 channels.
20. Favourite channel lists.
21. Automatic day light saving time updating.
22. MHEG-5 Engine
23. Freeview Playback 2 support.

INTRODUCTION


Thank you for purchasing this product. It will give you good service if you take note of all safety notices and recommendations.

Contents supplied :



REMOTE CONTROL

1. Press the mark on the cover and slide it in the direction of the arrow.
2. Insert the batteries making sure the polarities correctly match the + and - marks inside the battery compartment.
3. Attach the cover and slide it until it clicks into place.



Incorrect use of the batteries may cause them to leak or explode. Please follow the precautions below.



- Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type.
- Insert the batteries making sure the polarities correctly match the + and - marks inside the battery compartment.
- Batteries of different types have different properties, therefore do not mix batteries of different types.
- Do not mix new and old batteries.
This may shorten the life of new batteries or may cause old batteries to leak.
- Remove the batteries from the remote control once they have run out, as leaving them in can cause them to leak.
Battery fluid from leaked batteries is harmful to skin, therefore ensure that you wipe them first and then remove them using a cloth.
- Remove the batteries from the remote control if you will not be using the remote control for a long time.
- Comply with the rules accordance of each local government when disposing of worn-out batteries.

Replacement batteries for this unit are 1.5 Volt (R03/AAA).

GETTING STARTED

Before connecting, ensure that the power cord of the unit is unplugged from the AC outlet and turn off the devices to be connected. After making all connections (Diagrams on page 11), turn on the unit first and then the other devices.


After plugging in the mains cord, wait until a blue light is viewable on the front panel (Standby Mode). "NOTE" - When the unit is first powered up, please wait a short while before activating the receiver as the unit's software needs to be initialised and the hard disk checked.

You can turn on your unit by pressing the Standby button on the remote control. Notice that the blue light on the front panel will turn blue.


The unit is equipped with output terminals that support RGB, S-video and CVBS video signals. The image quality is highest in the order of the RGB signal, the S-video signal and the CVBS video signal.

FRONT AND BACK PANEL

FRONT PANEL




BACK PANEL




- | | |
|------------------------------|--|
| 1. AERIAL 2 IN | : Loop through |
| 2. AERIAL 2 OUT | : To watch analogue channels on the TV |
| 3. AERIAL 1 OUT | : Loop through |
| 4. AERIAL 1 IN | : Aerial input |
| 5. TV SCART | : TV Scart connection |
| 6. AUX SCART | : Output for other equipment such as DVD, VCR...etc. |
| 7. ANALOGUE AUDIO LEFT/RIGHT | : Analogue Audio output |
| 8. CVBS | : Video Output |
| 9. OPTICAL AUDIO | : Optical Digital Audio Output |
| 10. RS232 | : Service use only |
| 11. POWER SUPPLY | : 220-240V AC, 50 Hz |

CONNECTION DIAGRAMS




NOTE: This set top box supports Free To View only. There is no provision for a CAM or Pay To View card.

REMOTE CONTROL & FUNCTIONS



USING THE CONTROLS ON THE FRONT PANEL

You can enter the main menu by pressing the menu button on the front of the unit. Then navigate through the menus with the four arrow buttons on the front of the unit and make a selection with the OK button.

BUTTON	FUNCTION
1. Standby	ON / Standby
2. ►►	Search Forward
3. LIB.	Library of recordings
4. Timers	Timer Setup
5. 	Record key
6. Info	Information bar
7. Direction buttons / OK	Navigation / Skip 2 minutes (left/right)
8. Back / Exit	Exit
9. P+ / P-	Channel Up / Down
10. Yellow	Yellow Teletext function key
11. Blue	Blue Teletext function key
12. Number keys	Numerical keys
13. P◀ P	Swap channels (with last viewed channel)
14. Wide	TV aspect ratio mode
15. Subt.	Show / Hide Subtitles
16. Swap	Swap the channels shown on the PIP window and normal screen
17. PIP +	PIP Window Channel Up
18. Mute	Mute
19. ▶	Play
20. ◀◀	Search backward
21. ■	Stop
22. II	Pause / Timeshift
23. Guide	Electronic Program Guide
24. Text	Display Teletext
25. V+ / V -	Volume UP / DOWN
26. Green	Green Teletext function key
27. Red	Red Teletext function key
28. Aux	Toggle between TV and the input from any equipment connected to the AUX scart
29. Menu	Enter menu / Exit menu
30. Fav	Favourite list
31. PIP	Show / Hide PIP window
32. PIP-	Previous channel in PIP window


MENU INTERFACE

FIRST TIME INSTALLATION

When the box is switched on from stand-by mode and if there is no channel stored in the database, First Time Installation Menu window is displayed on the screen. In this window, set the TV type with “◀ / ▶” keys and press OK to continue.



The next menu will ask you, if you want to begin with the automatic channel scan.



MAIN MENU

Main menu is accessed by pressing the MENU key on the remote control. Navigate with “▲ / ▼” keys among the menus and press OK to activate menus. In some sub-menus, press the BACK button to return to the previous menu, otherwise, use it to exit from the menu. In all menus there is an Info banner at the bottom of the screen. These are functions that can be used in the current menu.



1. CHANNEL LIST

Channel list is the place where the channels are managed. The following operations can be performed in this menu:

1. Navigating channel list
2. Deleting channels
3. Renaming channels
4. Adding locks to channels
5. Setting favourite list



1.1. NAVIGATING CHANNEL LIST

In the channel table “▲/▼” moves the selection to the previous or next .To exit menu and watch a specific channel highlight it using, “▲/▼” then press OK key while the "SELECT" option at the bottom of the screen is highlighted. If the selected channel is password protected then a pop up menu is displayed. If the correct code is entered, the selected channel can be watched. You can now select another channel in the list. The scroll Bar in middle of the screen shows relative position of the currently visible channels with respect to the whole list.

1.2. DELETING CHANNEL

To delete a channel highlight it using “▲/▼”, then highlight the “Delete” button using “◀/▶”and press OK. A message is displayed to confirm your decision, if you still want to delete select “YES”, with the < > buttons or the operation will be cancelled if you select “NO”.

1.3. EDIT CHANNELS

To rename a specific channel, highlight "Edit Name" button after the channel is selected and press OK. A box appears on the screen. “◀/▶” moves to the previous/next character. “▲/▼” toggles the current character, i.e., 'b' character becomes 'a' on “▼” and 'c' on “▲”. Pressing the numeric buttons '0...9' replaces the highlighted character with the characters printed above the button one by one as the button is pressed. Pressing BACK cancels the editing and OK saves the new name.

1.4. ADDING LOCKS TO CHANNELS

Channel Locking provides a password-protected access to channels selected by parents. In order to lock a channel you should know the parental Lock password (set to 0000 in the factory and can only be changed from the Configuration Menu), from the channel list menu highlight the channel to be locked and select the “Lock” button with the < > keys, when OK is pressed a password box is displayed. Enter the parental Lock code, press OK and the Lock icon will be displayed in front of the selected channel. Repeat the same operation to cancel the Lock.

1.5. SETTING FAVOURITE LIST

Favourite lists provide an easy way to group programs in a customizable way. Five favourite lists are available on this product named as List1, List2, List3, List4 and List5.

- From the channel list use the “◀/▶” buttons to highlight “Favourites” and press OK to enter the “Favourite Lists” menu.
- Press the “◀/▶”buttons to select your preferred favourite list (List1/List2/List3/List4 or List5).



- Press OK to add the highlighted programme to your list and continue to add the programmes you want to include in your favourites by highlighting the channel and pressing OK.
- Repeat the above steps to remove the channels from the list. Once complete press MENU to save your settings.
- You can step through your favourite lists with the FAV button on the remote. Each press will advance to the next list. The PR+ and PR- buttons will cycle through the channels you put in the currently selected favourites list.

2. PROGRAMME GUIDE (7 DAYS EPG)

Electronic Program Guide appears on the screen. It is able to get Information of the channel - programs weekly by means of 7-DAY-EPG. All programs of channels are displayed. The current program is highlighted and there is brief information about the programs of the channel, such as: name, short/extended event description, start & end time. By pressing “◀/▶” keys continuously the time scale can be changed. If there is any event information data available only program names and dates are displayed. Across the bottom of the screen there is an info bar showing all the available commands which are listed below.



RED BUTTON (SHRINK)

GREEN BUTTON (EXPAND)

YELLOW BUTTON (PREV DAY)

BLUE BUTTON (NEXT DAY)

INFO (DETAILS)

OK (OPTIONS)

: make the info boxes smaller.

: make the info boxes larger.

: displays the programs of previous day.

: displays the programs of next day.

: displays the short extended programs in detail.

: shows the programme options include “Select Channel”, “Record / Delete Timer”, “Series Record / Series Delete Timer”, “Check Conflicts” and “Set Reminder / Delete Reminder”.

NUMERIC BUTTONS (JUMP)

RECORD

◀ (PAGE LEFT)

▶ (PAGE RIGHT)

TEXT (SEARCH)

▶ (NOW)

: go to preferred channel directly via numeric buttons.

: the unit will record the selected programme.

: moves the page to left.

: moves the page to right.

: activates “Search” window.

: shows the current programme.

2.1. PROGRAMME OPTIONS

In EPG menu, press the OK button to enter the “Programme Options” menu.



2.1.1. SELECT CHANNEL

In EPG menu, using this option, you can switch to channel of the programme that is selected.

2.1.2. RECORD / DELETE TIMER

In EPG menu, after you have selected a programme, press the OK button and select the “Record” option in the menu which appears and press the OK button again. So a recording is set to the selected programme. This option operates like the RECORD button.


To cancel an already set recording, highlight that programme and press the OK button and select the option “Delete Timer”. The recording will be cancelled.

2.1.3. RECORD SERIES / DELETE SERIES TIMER

In EPG menu, after you have selected a programme, press the OK button and select the “Record Series” option in the menu which appears and press the OK button again. So a series recording is set to the selected programme. With this feature, you can record a programme and all of its following parts within 7 days. The information belonging to the selected programme will be saved from the software and following parts of the selected programme which are not included in the period of 7 days, will be automatically added day by day. The letter “s” denotes that these recordings are series records.

To cancel an already set series recording, highlight that programme and press the OK button and select the option “Delete Series Timer”. The recordings will be cancelled.

Note: Series programme informations should be broadcasted by the broadcaster.



Name	Start	Length	
Neighbours	27/02/07 13:40	25m	s
Neighbours	28/02/07 13:40	25m	s
Neighbours	01/03/07 13:40	25m	s
Neighbours	02/03/07 13:40	25m	s
Neighbours	05/03/07 13:40	25m	s
Neighbours	06/03/07 13:40	25m	s

2.1.4. CHECK CONFLICTS

A conflict is caused, if more than two programmes are set for recording in the same time interval or if two reminders have the same starting time. In the EPG menu, press the OK button. In the following window, select the option “Check Conflicts” and press again the OK button. You will enter the “Too Many Timers” window.

2.1.5. SET REMINDER / DELETE REMINDER

In EPG menu, after you have selected a programme, press the OK button and select the “Set Reminder” option in the menu which appears and press the OK button again. You can set a reminder for future programs.

To cancel an already set reminder, highlight that programme and press the OK button and select the option “Delete Reminder”. The reminder will be cancelled.

2.1.6. SPLIT RECORD

If you select a programme to be recorded, with this feature, if there is another part of the programme available, it will also be set automatically to be recorded. For example in the following picture you see the programme with a red underline, which following episode is also underlined. To do this, you have to press only the RECORD button once. The rest will be done automatically.

Note: Split programme informations should be broadcasted by the broadcaster.



2.1.7. MULTIPLE / ALTERNATIVE TIMER RECORD

It is possible to record or set reminder for two individual events at the same time interval. If you set more than two recordings/reminders at the same time, you will see an error message.



INFO: Pressing this button, gives you detailed information about the selected programme.

Record/Cancel: Sets recordings for the selected programme. If you press it again, the recording will be cancelled.

OK: Pressing this button will save the latest changes and you will leave this window and go back to the EPG window.

Alternatives: If you press this button, you will get alternatives for the programme which causes a conflict.

NOTE: A conflict is caused, if more than two programmes are set for recording in the same time interval or if two reminders have the same starting time. To solve this conflict, you have to select an alternative for one of those programmes or cancel one of the reminders.



NOTE: If there is still a conflict and you leave this menu by pressing the OK button, you will see this warning message: "There are still conflicts!". In timer menu, you can see this conflict as the picture below. A warning triangle will appear nearby the programmes which cause a conflict. These programmes will be recorded particularly or not.



3. TIMERS

To display Timer window press either TIMERS key or activate it from main menu. The features of this menu are like below:

Delete: You can delete the highlighted single timer or series timer.

Edit: You can edit the saved timers.

Add: By pressing this button, you will go to the "Add Timer" menu.

Options: If you press the OK button, you can select the "Delete Timer", "Delete Series Timer" and "Check Conflicts".



To add a Timer press YELLOW button on the remote and the, "Add Timer " windows appears.

Channel: "◀ / ▶" keys will navigate the user through the TV or Radio list.

Date: By using either "◀ / ▶" or "0,1,2...,9" keys start date is entered.

Start: By using either "◀ / ▶" or "0,1,2...,9" keys start time is entered.

End: By using either "◀ / ▶" or "0,1,2...,9" keys end time is entered.



Duration: Displays the duration of the recording. This is automatically worked out after the start and end times have been entered.

Playback: permit or block playback for other users."use parental settings" is default.

Change /Delete: permit or prohibit any modifications for other users.

When a timer Start time is reached, the receiver starts to record the desired program, then when the end time is reached, the record stops. Save the adjustments by means of GREEN key or cancel with RED button. Edit the list via GREEN key and delete with the RED button.

4. RECORDINGS LIBRARY

All the recordings are kept in list. To show the list of recordings press either LIB button on the remote or access it from the main menu.



RED BUTTON (DELETE)

GREEN BUTTON (EDIT)

YELLOW BUTTON (TAG)

BLUE BUTTON (SORT)

INFO (DETAILS)

OK BUTTON

▶ **(RESUME)**

: Erase the recordings

: make changes to the recordings

: marks the recordings for archiving

: change the order of the recordings

: displays the short extended programs in detail

: opens the play options menu

: recommence the recordings

Red bar: indicates the used space of the recordings on the hard disk.

Yellow bar: displays the approximate capacity required for the timers currently set.

Green bar: shows the free space on the hard disk.



4.1. PLAY OPTIONS

4.1.1. PLAY FROM START

Plays the recording from the beginning.

4.1.2. RESUME

Begins with playing from the last stopped position.

4.1.3. PLAY FROM OFFSET


Begins with playing, from the time which is entered.

4.1.4. MANAGE CHAPTERS

It will display any marked chapters (To set chapter marks, press the Menu button during playback and enter the "Chapter Options" menu) and begin with playback from the selected chapter.

4.1.5. CREATE ARCHIVE (ARCHIVE MANAGEMENT)

Using this option, you will be able to archive your recordings to an external device like a DVD player. Press the LIB. Button and come to the "Recordings Library". In this library, the saved recordings are listed. To select a recording which should be archived, highlight one of them using the "▲/▼" buttons and select the TAG option, by pressing the yellow button. After then, press the OK button to open the "Play Options" menu. In this menu, using the "▲/▼" buttons, select the "Create Archive" option and enter it by pressing the OK button. You will see the menu below:



EDIT RECORDINGS

While the “Edit recordings” option is highlighted, using the “◀ / ▶” buttons come to the list of recordings on the right of this menu. Select one of them, which should be archived and press the OK button. You will come to the following menu:



Edit recording details	
Name	gin: Thomas The Tank E...
Recorded on	Fri 03/03, 08:30
Recording length	29m 56s
Start recording at	0m 0s
Stop recording at	End
Archive length	29m 56s

Here, only the “Start recording at” and “ Stop recording at” options are active. If you have already separated recording, you could select any chapter to begin with the archiving and stop it. If it is not separated in chapters, the beginning and ending time of the recording will be automatically the beginning and ending time of the archiving.

MAIN TITLE

If you want to display a main title, select “Include” (To do this, use the “◀ / ▶” buttons). If not, select “Skip”. By selecting “Skip”, the options below will be disabled.

TEXT: After you select the “Include” option in the “Main Title” menu, you could edit the main title.

DURATION: Set the duration of the appearance of the main title on the screen.



RECORDING TITLE

If you want to display a recording title, select “Include” (To do this, use the “◀ / ▶” buttons). If not, select “Skip”. By selecting “Skip”, the options below will be disabled. While archiving, you could decide to show the names of the saved recordings on the screen.

DISPLAY: In this option, you could decide, which of the following items should be displayed in the recording title: “Name”, “Start date/time” and “Length”.




Edit recording title	
Name	◀ Include ▶
Start date/time	Include
Length	Include

DURATION: Set the duration of the appearance of the “Edit recording title” menu main title on the screen. If you press the Menu button during playback, you will enter the “Chapter options and in this menu, you could set any point as a chapter. So, the user is be able to skip frames which should not be archived. The user could also start and stop the playback from any chapter he wants. To stop archiving, press the STOP button. During archiving, no other button will be function.



4.2. CHAPTER OPTIONS

During playback of a recording, if you press the MENU button, you will get to the “Chapter Options” menu. The chapter options menu includes following options:



This menu includes the options below:

4.2.1. CREATE NEW CHAPTER MARK

Using the “▲/▼” buttons select this option and press the OK button, to create a chapter mark. You could set a chapter mark anywhere you want.

4.2.2. FORWARDS TO NEXT CHAPTER

Using the “▲/▼” buttons select this option and press the OK button, to go to the next chapter. If there is more than one chapter.

4.2.3. BACK TO START OF CHAPTER


Using the “▲/▼” buttons select this option and press the OK button, to go to the beginning of the current chapter. This is the last played chapter.

4.2.4. BACK TO PREVIOUS CHAPTER

Using the “▲/▼” buttons select this option and press the OK button, to go to back to the previous chapter. If there is more than one chapter.

5. SETUP

The adjustments in this menu are:




5.1. RECORDINGS


The internal hard drive can store up to 80 hours of digital TV broadcast (depending on the data rate of the recorded programme, which is set automatically by the broadcaster).

Because the PVR has a Twin Tuner it is possible to record two events and watch two programmes at the same time. It is also possible to playback a recording previously made during an active recording.

The PVR record and playback functions are very similar to those of a VCR. The buttons used for playback and recording are shown below.



To configure the playback/recording options select the "Recordings..." option from the configuration menu. The following options are available for adjustment:



5.1.1. MAX TIMESHIFT

Select the maximum time allowed for timeshifting. See below for more information on timeshifting

5.1.2. AUTO DISCARD

Discard: When the HDD is full and a timer is set to record, the unit will automatically discard previous recordings based on this setting. The options are as follows:

None: The unit will not discard any recordings and the timer will not record the requested programme.

Oldest: Starting with the oldest, recordings will be deleted to make space for the requested timer.

Longest: Starting with the longest, recordings will be deleted to make space for the requested timer.

Shortest: Starting with the shortest, recordings will be deleted to make space for the requested timer.

Unplayed: If this option is set to "EXCLUDED" any unplayed recordings will NOT be deleted. If this option is set to "INCLUDED", unplayed recordings WILL be deleted.

5.1.3. FORMAT DISK

On rare occasions the Hard Disk may malfunction, in most cases formatting the Hard Disk will restore normal operation however ALL the data stored on the Hard Disk will be lost. Press OK with the "Format Disk" option is highlighted. A menu appears, in which you will be asked for a pin number. If you have not changed the pin number, the factory default is 0000. After you enter it, a pop-up menu appears on the screen to ensure that the hard disk should be formatted, select "YES" and press OK to format the Hard Disk. Select "NO" and press OK to cancel. Ensure you dub important recordings onto Video or DVD before you format the HDD.

5.1.4. HARD DISK INFO

To view the details about the Hard disc, highlight "Hard Disk Info..." using "(up)/(down)" keys and press OK. The following information will be shown:

Total Space: The total size of the Hard Drive

Reserved for timeshift: This is the space that is reserved for use by the timeshift function and is dependant on the setting in "Max timeshift" (see page 21 for details)

Space used by recordings: The space used by the recordings that are on the Hard Drive

Free Space: Available space for future recordings

Estimated space for times set: The estimated space on the hard drive that will be used for the any timers that are currently set

Estimated Recording Time remaining: This is the estimated remaining time left available for recordings. The settings of the recordings are configured in this menu, press OK to display the menu.



Hard disk information	
Total space	159.8 GB
Reserved for timeshift	3.7 GB
Space used by recordings	0.1 GB
Free space	156.0 GB
Estimated space for timers set	0.0 GB
Estimated Recording time remaining	75 h 15 m

This Recorder has a built in hard disk (abbreviated as HDD) for recording and playback. Beware of the following points when setting up and using the Recorder. Failure to observe precautions may cause damage to the HDD itself or its content, failure of the disk to operate, or recording of noise.

- Do not subject the Recorder to any vibration or impact.
- Do not place the Recorder in a cramped location which might block the ventilation port on the back of the Recorder.
- Do not place the Recorder in a location with severe temperature variation.
 - If the Recorder is set up in a location with severe temperature variation, dew may form on and inside the Recorder. If the Recorder is used with internal dew formation present, this may cause HDD damage or malfunction. We recommend keeping variation in room temperature within 10°C per hour.
- Do not place the Recorder in a location with high humidity.
- Place the Recorder horizontally, never at an incline.
- Do not place a magnetic device (magnet etc.) close to the recorder.
- When the power is on, do not unplug the power cord from the AC outlet, turn off the breaker for the area where the Recorder is set up, or move the Recorder.

When moving the Recorder, first turn off the power and then unplug the power cord from the AC outlet.

Recording Format

- **HDD recording is done using the variable bit rate format (VBR) for more efficient recording. The following phenomena may occur.**

With the variable bit rate format, the remaining amount which can be recorded may increase or decrease relative to the display of the remaining amount of HDD space.

- When the display indicates that the remaining amount of HDD space is low, first delete unnecessary programmes, and then record with an extra margin in the amount of remaining space. There is an option in the configuration menu to discard the recordings. You can choose between three options:
Deleting,
1 – Oldest recordings
2 – Largest recordings
3 – Smallest recordings
When the HDD is out of space, it will operate regarding one of these options and delete the recordings.
- Even if you delete a programme, the remaining amount may not increase by the amount of deleted time. When recording new video, record with an extra margin in the amount of remaining space.

Unrecordable Material

In the unlikely event that there is some problem like loss of recorded video or audio content due to an HDD malfunction, please be aware beforehand that we will bear no responsibility to compensate for the content which could not be recorded or edited, for the loss of recorded or edited video, or for other related direct or indirect damages.

- **If a power failure occurs**

- The content being recorded or timer recorded may be damaged if power failure occurs.
- The content being played back may be damaged.

- **For important recording**

- If the HDD malfunctions, the content recorded on the HDD may be lost. If you wish to save content permanently, we recommend copying or moving the content to Video or DVD.

NOTE

- If a message indicating an HDD error is displayed (such as “ERROR IN HDD. CANNOT OPERATE.”) and the HDD has malfunctioned, you cannot replace the HDD by yourself. If you disassemble the Recorder, the warranty will become void. Also, recovery of data is impossible. If playback is possible, re-record the recorded content onto a Video or DVD, and contact the approved service centre with the details provided at the front and back of this operation manual.

Hard Disk Operation (Recording / Playback / Time Shift Recording)

If the Recorder is used in a cold location (a location at low temperature), the drive will only allow live viewing after power is turned on until the HDD is ready. During this time, the Recorder will not allow Time Shift Viewing, recording, display of recording lists or playback of recorded programmes. Please wait until the HDD is ready.

5.2. CONFIGURATION

You can configure the settings of your set top box. Select Configuration from Setup menu and press **OK** to enter this menu. Press the **BACK** button on the remote to exit.

5.2.1. TV TYPE

Digital terrestrial television channels can broadcast programmes in a widescreen format which must be output differently to normal and widescreen TV sets. This function tells the receiver the screen format of the TV connected so that broadcasts are displayed correctly. Highlight the TV Type line in the Configuration menu and use



the “◀ / ▶” keys to select 4:3 if you have a standard TV set connected or 16:9 if it is a widescreen TV. This function duplicates the selection made at the time of first installation and can be used if you change TV sets.

5.2.2. TV OUT

The receiver can output RGB , CVBS and S-Video signal from the TV SCART on the rear panel. Although the RGB format results in a better quality picture, not all equipment can cope with an RGB signal.

5.2.3. VCR OUT

This allows you to select CVBS or S-Video output from the VCR SCART socket. The receiver can output SVideo and CVBS signal from the VCR SCART on the rear panel.

5.2.4. FAVOURITE MODE

This function enables or disables the 5 favourite channel list mode by pressing “◀ / ▶” buttons and press **OK** . IF a favourites list exists it will switch to the list number selected. If there is no favourite listing, a warning message is displayed.

5.2.5. CHANNEL LIST


Use “▲ / ▼” buttons to go to Channel List option. Use “◀ / ▶” buttons to toggle Channel List Mode. If you select “TV Only” you navigate through only TV channels, if you select “Radio Only” you navigate through only radio channels, if you navigate “Text Only” you navigate through only Text channels with the **PR+ / PR-** buttons. If you choose “Show All” all, channels can be navigated with the **PR+ / PR-** buttons. To save the recent changes and exit; press the **MENU** button.

5.2.6. SCAN ENCRYPTED CHANNELS

Use “▲ / ▼” buttons to go to the Scan Encrypted Channels option. Use “◀ / ▶” buttons to toggle YES or NO the searching for encrypted channels.

5.2.7. RECEIVER UPGRADE - OAD

Over Air Download (OAD): To ensure that your STB always has the most up to date information. Please ensure that after use it is set to its standby mode. The STB automatically powers up at 3.00 A.M. each day and searches for any new information which may be broadcast and will download this to your receiver automatically. This operation will normally take approximately 30 minutes. If you have an important recording to make at 3.00 A.M. which must not have a 30 minutes interrupt then you can disable the auto OAD search by performing the following:




- Press Menu button and using the “▲/▼” buttons to choose Setup and press the OK button.
- Highlight Configuration menu with “▲/▼” keys and pres OK.
- Use “▲/▼” buttons to choose "RECEIVER UPGRADE" and press OK button.
- Using the left / right button change “Automatic scanning” from Enabled to Disabled.
- Highlight “Scan for upgrade” menu with “▲/▼” keys and pres OK to commence upgrade.

Do not forget to re enable the automatic OAD function after you have made your recording by repeating the above instructions but this time selecting ENABLE.

5.2.8. PARENTAL LOCKING

Use “▲/▼” buttons to go to Parental Lock option. Press OK button to enter the menu. A box asking for the lock key is displayed. The key is set to “0000” initially. Enter lock key. If it is incorrect, "Wrong Pin" is displayed. If it is correct, the Parental Control Menu is displayed.



5.2.8.i. MENU LOCK

In menu lock you can set locking for All Menus, or the Installation Menu to restrict access to these menu's. If the menu lock is disabled, there will be free access to the menu system. Use “▲/▼” buttons to go to Menu Lock option. Use “◀ / ▶” buttons to choose Menu Lock Mode.

DISABLED : All menus are unlocked.

ALL MENUS : All Menus are accessible only with the correct lock key. So the user can't add, delete, rename, channels, can't set timers.

INSTALLATION MENU : Installation menu is locked. So the user can't add channels. Changes will be updated after exiting 'Configuration Menu'.


5.2.8.ii. SET PIN

The PIN code of the unit changed. Use “▲/▼” buttons to go to “Set PIN” option. Press OK to display the “Set PIN” window. Use NUMERIC buttons to enter new pin number you will need to input your new pin a second time for verification purposes. If Both pin numbers are four digits long and the same, the pin will be changed. The factory default pin number is 0000, if you change the pin number make sure you write it down and keep it safe.



5.3. LANGUAGE

In this menu the user can adjust the preferred language. Language is changed by pressing OK key.



Menu: shows the language of the system

Preferred

These settings will be used if available. Otherwise the current settings will be used.

- **Audio:** by pressing “◀ / ▶” keys change the audio language.
- **Subtitle:** alter the subtitle language with “◀ / ▶” keys. The chosen language will be seen in subtitles.

Current

- **Audio:** if audio language is supported change the audio language by pressing “◀ / ▶” keys
- **Subtitle:** if subtitle is backed up alter the subtitle language with “◀ / ▶” keys. The chosen language will be seen in subtitles.

5.4. INSTALLATION

5.4.1. AUTOMATIC CHANNEL SCAN

Automatic channel scan is activated by selecting OK when the line is highlighted. A pop-up menu appears on the screen, select “YES” the automatic scan begins. All the multiplexes are searched and a channel table is created automatically. All channels found are stored in a sorted form with respect to their channel numbers. Selecting "NO" will cancel the operation.



5.4.2. MANUAL CHANNEL SCAN

In manual search the number of the multiplex is entered manually and only that multiplex is searched for the channels. In manual and auto search, any existing channel in the database is not re-stored to avoid redundant duplicates of that channel. To start the scan enter the channel number manually and press OK.

5.4.3. FIRST TIME INSTALLATION


Use this option to load default settings, which had been set at the factory. To install factory settings, highlight 'First Time Installation' menu and press OK key, then you will be asked to confirm deleting all channels and settings. Selecting YES and pressing OK will delete the channel table. Selecting "NO" and pressing OK will cancel the operation.

6. MESSAGES

When the box receives no signal (e.g. the antenna cable is disconnected), "NO SIGNAL" message is seen on the screen.



When there are no channels stored in the box; the Channel List menu is not accessible. Channel navigation is not allowed. Therefore, trying to enter these menus or navigate the channels will display an error message on the screen.



A conflict is caused, if more than two programmes are set for recording in the same time interval. To solve this conflict, you have to select an alternative for one of those programmes. If there are no alternatives, the warning message on the right will appear.



If there is still a conflict and you leave this menu by pressing the OK button, you will see this warning message: "There are still conflicts!".



7. SPECIFIC FUNCTIONS OF REMOTE CONTROL

When there is no menu active on the screen, each of the keys have specific functions.

OK KEY: when OK key is pressed Channel list appears on the screen.

RECORD KEY

The programs are recorded at once. 

- Record time is attained from EPG automatically. If the program has EPG information, you could set the timer. If there is no EPG info, press the Record button to set the timer in 30 minutes periods.
- In EPG by pressing the record key, programs are recorded instantly.

LIB KEY: by pressing this key, you will get to the Recordings Library, which shows you the details of your saved recordings. By pressing it again, you will exit the Recordings Library.

SUBTITLE : subtitle key shows/hides subtitles of channel. When the subtitle key is pressed, subtitle ON/OFF message is displayed.

INFO KEY

When INFO key pressed, and when changing channels the information window is displayed on the lower part of the screen. The small bar indicates the program duration. On the channel info window there are



- Current event name next event name, and their start and end times.
- Program duration bar
- Program mode (TV or Radio)
- Channel number
- Name of the channel

The second press of the info button brings up a box containing a brief description of the currently viewed programme.

You can now use the > button to change the programme description to that of the next programme on the current channel.

PR+ / PR – (CHANNEL NAVIGATION)

There are two ways to navigate through the channels:

- Pressing PR +/ PR - keys will take you to go to the next or the previous channel in the list.
- Pressing a number key will activate a small digit entry window on the left upper corner of the screen. After a digit is entered, the box will stay for 2 seconds while you enter another digit. If no digit is entered during these 2 seconds, then the box will switch to the entered number channel. If a number that is greater than the maximum number of channels is entered, the box will switch automatically to the last channel.
- Press OK button to display the channel list.

VOLUME CONTROL

The volume level of the sound from the receiver can be altered with the VOL+ and VOL- keys on the remote control handset. Pressing either key displays



a bar graph of the sound volume on the TV screen. The volume level selected will remain set, even when the receiver is turned off and on again, until it is altered with VOL + and VOL - keys. The audio volume adjustment for the receiver is independent of the volume control on your TV set. Be careful that both volume controls are kept within reasonable levels so that when switching from analogue to digital television viewing, or when first turning on your TV set, the sound level is not too high.

You can silence the sound from the receiver by pressing the MUTE key. The sound remains muted until the MUTE key is pressed again, the VOL + or VOL- keys are pressed. While the sound is muted in this way, the mute symbol is displayed in the top left of the TV screen. The symbol is removed after 3 seconds, but the sound will remain muted until the MUTE key is pressed for the second time and the mute symbol will display for 3 seconds.



PIP (PICTURE-IN-PICTURE)

Enables / disables PIP window.

- **PIP +:** next channel in PIP window.
- **PIP - :** previous channel in PIP window.

NOTE: PIP is only available when LOOP THROUGH is connected. (Please see page connection diagrams)




SWAP

Main window and PIP window change their places.


TIME SHIFTING (PAUSE LIVE RECORDING)

Pause Live Recording is a feature that enables you to pause a live broadcast if, say the phone rings you can go back to the same spot that you were at when you left. The live broadcasting can be stopped

any time. Press PAUSE  button to suspend the broadcasting. In the INFO banner the timeshift will commence. The duration of Timeshift can be adjusted from Recordings in the Configuration menu (See 5.1.RECORDINGS). In order to stop the timeshift press PLAY, PAUSE or OK button. The paused recording can be watched in different speeds by means of



keys. To terminate the

Pause Live Recording press  button.



NOTE:

You can also use the PAUSE button on the front of the unit if you wish.

TEXT

Many digital terrestrial television channels not only broadcast pictures and sound for programmes but also pages of information on the programmes, the weather, news and many other topics. This digital teletext can be displayed by the receiver. Some channels are entirely given over to digital teletext and carry no normal TV programme at all.

These dedicated digital teletext channels will not give a quarter-screen image in the EPG or the Channel List screen. When such a channel is selected, after a brief pause, they will usually display the opening page of information automatically. Other channels have digital teletext pages broadcast alongside the television programme and often include a reduced-size broadcast picture within digital teletext pages.

These usually require the TEXT button to be pressed to activate the digital teletext pages. In both cases, moving through the different pages of information is accomplished in a variety of ways, dependent on the individual broadcasters, but including use of the “▲/▼/◀/▶” and [OK] keys to select items from on-screen menus, and the coloured keys to jump directly to particular pages.

You can exit teletext mode by pressing the TEXT button on the remote or by changing channel. Also if you call for the INFO bar or bring up a menu you will temporarily enter TV mode returning to TEXT mode when you cancel the menu or INFO bar.

You can exit any digital teletext channel by changing channel in any of the normal ways. You can leave the digital teletext function of a combined digital teletext/programme channel, to return to normal television viewing of that channel, by pressing the TEXT key. Calling for the information banner or any menu on-screen stops the receiver from displaying the digital teletext pages and they are temporarily replaced by a blank picture while the banner or menu is displayed. Digital teletext cannot be accessed when the Subtitles are enabled.

WIDE

TV sets are available with screens of the standard (4:3) format and widescreen (16:9) format. When you first installed your receiver you specified the format of the connected TV (this can now be altered if necessary; see Configuration) Digital terrestrial television broadcasts are also made in both standard and widescreen formats. In particular, films and dramas tend to be broadcast in widescreen format to closer emulate the cinema experience, but some programmes such as news bulletins are 4:3. To help get the most from both TV set and programme when a widescreen film is watched on a standard TV, or a standard broadcast is viewed on a widescreen set, the receiver includes the WIDE key. So long as the receiver has been correctly set up for the TV set connected, a widescreen programme will always be displayed correctly on a widescreen set, and a standard format programme will correctly fill the screen of a standard format TV.

With a widescreen TV set displaying a standard format programme the WIDE key switches between displaying the picture with black bars down the sides, and enlarging the picture so that it fills the whole width of the screen but the top and bottom are cropped off. With a standard format TV displaying a widescreen programme, the WIDE key switches between displaying the picture with black bars at the top and bottom of the screen, and filling the whole height of the screen but cropping the sides off according to instructions broadcast with the programme (called 'pan and scan'). The effect of the WIDE key on the picture display is cancelled by pressing WIDE again.

NOTE:

Sometimes the TV will automatically try and compensate for an incorrect screen format, in this instance set the tv to the correct format whilst viewing the programme.

8. TROUBLE SHOOTING GUIDE

Problem	Possible Reason	What to do
The LED indicator does not glow	Mains cable is not connected	Check if the main cable is not plugged into the power socket.
No picture or sound	No signal or weak signal.	Check the Aerial and scart connections
The settings you have made in the menus have not been changed.	The digital set-top box was unplugged without first going to standby.	Before unplugging your digital set-top box, make sure it is in standby
The remote control is not working.	The digital set-top box is in Stand by. Remote control is incorrectly aimed. Battery exhausted.	Press the standby key. Check if anything is obstructing the front panel . Change the batteries
Password forgotten.		Take contact with the nearest service center.
Record does not start.	No or weak Aerial 2 input Signal.	Check Aerial 2 input connection.
No PIP video.	No or weak Aerial 2 input Signal. PIP Channel is radio or teletext based.	Check Aerial 2 input connection. Use PIP+ / PIP- to choose a valid TV channel.

9. TECHNICAL SPECIFICATIONS

GENERAL CHARACTERISTICS	
Supply Voltage	220 - 240 V AC ~ 50Hz
Input Frequency	470Mhz-862Mhz
Maximum Power consumption	21 W
Standby Power Consumption	13 W
Operating temperature	5°C to +45°C
Storage temperature	-15°C to +55°C
Humidity	25 to 75 % rel
Physical dimensions	360x280x48 mm
Weight	2820 g
HARDWARE CONFIGURATION	
Main Processor	STM5100
Flash Memory	4 MB
DDRRAM	64 MB
DIGITAL CAPABILITIES	
Transmission Standards	DVB, MPEG2
DEMODULATION	
COFDM	with 2K/8K FFT mode.
FEC	for all DVB Modes.(Automatically found)
VIDEO	
ALL MPEG-2 MP@ML Video Decoder	
Aspect Ratio	4:3, 16:9 with pan vector
RGB analogue outputs.	BW ≥ 5MHz at 0.5 to 5 MHz sweep signal
CVBS analogue output.	
AUDIO	
MPEG1 Layer 1 and 2	
Sampling frequencies supported	32 kHz, 44.1 kHz or 48 kHz.
Output can be programmed as STEREO, LEFT only or RIGHT only (on both outputs). This is useful for dual mono channels in order to select the correct sound track, which is stored for every channel.	
Wide dynamic range	16-bit resolution

REMOTE CONTROL	
Operating Distance	10 m Max.
Batteries	2x1.5V Micro (R-03/AAA)
TUNERS	
2 xRF In	IEC-type, female (75Ohm)
2 x RF Out (loop through)	IEC-type, male (75Ohm)
HARD DISK	
Hard Disk capacity	160 GB
FRONT PANEL	
Display	VFD
Front Panel Controls	Standby ON/OFF, Menu, Record, Pause, OK, Menu Up/Down/Left/Right.
AUDIO R / L	
Connector	2 x RCA (R + L)
Output	2 Vrms, 0 dBfs / Z = 10 kohm
DIGITAL AUDIO	
Output	Optical SPDIF
A / V & DATA IN / OUT	
Scart	TV scart, AUX scart
RGB Video Output	TV scart
RGB Video Input	AUX scart
CVBS Video Output	TV scart, AUX scart
CVBS Video Input	AUX scart
Analog Audio Output	TV scart, RCA jack, AUX scart
Analog Audio Input	AUX scart
Digital Audio Output	Optical output
Data Interface	RS232 (max 115200 bps),9Pin

* Any changes in the Instruction Manual format is reserved.

10. Product Guarantee

This product is guaranteed against manufacturing defects for a period of

1 Year

This does not cover the product where the fault is due to misuse, abuse, use in contravention of the instructions, or where the product has been the subject of unauthorised modifications or alterations, or has been the subject of commercial use

In the event of a problem with the product within the guarantee period please return it to your nearest store

If the item is shown to have had an inherent defect present at the time of sale, the store will provide you with a replacement

Your statutory rights remain unaffected

Guarantor; Home Retail Group
489 – 499 Avebury Boulevard
Central Milton Keynes
MK9 2NW

11. IMPORTANT NOTICE:

DIGITAL SWITCHOVER AND YOUR TV EQUIPMENT

WHAT YOU NEED TO DO TO ENJOY WATCHING TV DURING AND FOLLOWING DIGITAL SWITCHOVER

Starting in 2008* and ending in 2012, television services in the UK will go completely digital, TV region by TV region.

To continue using this digital TV equipment during and following digital switchover, you will need to "reset" your digital TV channels.

Users of this digital TV DTR must reset their channels on at least 2 different occasions, normally 1 month apart when switchover happens. Digital UK, the body leading digital TV switchover, and broadcasters will advise you when to reset your channels on each occasion.

If you do not reset your channels, you risk losing some or all of your TV services during and following switchover.

Please refer to this instruction manual for help with resetting channels. The instructions for resetting the channels are on page 15 of this manual.

Please note that in order to receive the maximum number of available TV services on your equipment you must perform a first time installation and do not just add channels.

For more information about this, please contact our helpline using the above contact details or visit www.digitaluk.co.uk.

* With the exception of Whitehaven in Cumbria and the surrounding area which will switch over in October 2007.

The FREEVIEW service is subject to coverage. An aerial upgrade may be required. The FREEVIEW PLAYBACK word and logo are trade marks of DTV Services Ltd and are used under licence. © DTV Services Ltd 2006."


1 BEFORE YOU START

This Digital TV Recorder (DTR) can only receive and record Digital Terrestrial TV (Freeview) signals. Please check that you are in a Digital TV reception area. The FREEVIEW service is subject to coverage. An aerial upgrade may be required. FREEVIEW TM and logo © DTV services Ltd 2002. To check FREEVIEW coverage in your area now text your postcode to 83331 for a reply in seconds (standard network charges apply), telephone 08708 80 99 80 or visit www.freeview.co.uk Please check that all the following accessories are included and then insert the batteries in the remote control, ensuring that they are the correct way round.


Accessories:

- 1 Remote Control & 2 x AAA batteries
- 1 Operation Manual
- 1 Scart Cable (21 pin cable)
- 1 RF Cable

2 CONNECTION



3 REMOTE CONTROL



4 GETTING STARTED

Connect all cables before plugging in to mains. When the set-top-box is first powered up please wait for a while before activating the receiver since booting of software will take


some time. Then, you can turn on your digital set-top box by pressing the **STANDBY** button on the remote control.

5 FIRST TIME INSTALLATION

➤ Set the TV type with “◀/▶” keys and press OK. You can select Normal 4:3 or Widescreen 16:9 if you have a widescreen TV.



➤ Automatic channel scan window appears and the unit starts to search for channels.



6 MAIN MENU

Main menu is accessed by pressing the **MENU** key on the remote control.



➤ Navigate with “▲/▼” keys among the menus and press **OK** to activate menus.


➤ The list of the programmes,

Channel List, Electronic Programme Guide, Timers, Recordings Library and Setup menu are reached from main menu.

➤ Press **BACK** to exit the main menu.

7 CHANNEL LIST

Channel list is the place where the channels are managed. The following operations can be performed in this menu:



- Navigating channel list
- Deleting channels
- Renaming channels
- Setting favourite list
- Adding locks to channels

8 SETUP

The entire settings and configuration of the unit is adjusted in the SETUP menu. To activate setup menu in main menu press **OK**, when it is highlighted. Setup menu appears on the screen. Navigate within this submenu by means of “**▲/▼**” keys.



9 RECORDINGS

RECORD WITH SINGLE KEY

NOTE: The HDR162 has two tuners so you can make a recording of one digital channel and watch a different digital channel on the TV.

- To record a programme simply press the RECORD key
- The recording time of the programme will be automatically obtained from the Electronic Programme Guide (EPG).
- It is also possible to record a programme in the EPG by selecting it and pressing the RECORD button

ADD RECORDS VIA TIMERS

Programmes can also be recorded by means of “Timers” menu. Select “Timers” from Main Menu and press OK.

- Press YELLOW button to add a new recording.
- Select what you want to record.
- Press GREEN button to store it.
- When the programme starts it will be automatically recorded.




RECORDINGS LIBRARY

All the recordings are kept in “Recordings library”. To show the list of recordings press either LIB. button or access it from main menu.

Red bar: Indicates the space used on the Hard Disk.

Yellow bar: Yellow bar shows how much space has been set for timer recordings.

Green bar: Shows the free space on the hard disk.




PAUSE LIVE RECORDING

This feature allows you to freeze a programme if you need to leave the TV for a while and resume watching the programme from the same point when you return. Simply Press the (pause) button and the HDR162 immediately start to record the programme being watched. When you return simply press the (pause) key again and it will start replaying whilst continuing to record. At the end of the programme press the stop button.

Model
HDR162

DIGITAL TV RECORDER



QUICK START GUIDE

Instruction manual

To obtain the best performance and ensure years of trouble-free use, please read this instruction manual completely.

HITACHI

Inspire the Next

www.hitachidigitalmedia.com